

FUNCTION MAPPING for the ESU LokSound Select

Factory Generic Sound Files without Full Throttle

Diesel Locomotives

Key Functions

F0	Directional Headlights
F1	Bell [Optional]
F2	Horn
F3	Coupler
F4	Dynamic Brakes
F5	AUX1
F6	AUX2
F7	Switching Mode - Reduces Speed 50%
F8	Sound (On/Off)
F9	Manual Notching (up)
F10	Manual Notching (down)
F11	Radiator Fan
F12	Dimmer (Headlights)
F13	AUX3
F14	AUX4
F15	Spitter Valve
F16	
F17	Brake Set / Brake Release
F18	Sanding
F19	Short Air Let Off
F20	Compressor
F21	

For more info please see the ESU Instruction Manual Section of their Website.

<http://www.esu.eu/en/downloads/instruction-manuals/digital-decoders/>

DCC Solutions

DCC and Sound Installations, Custom Installations, Modifications, DCC Sales and Repairs
Contact: info@dccsolutions.com.au Website: www.dccsolutions.com.au